


RANGE TASK SEATING

RANHD 24/7

Chair Operating Instructions



RANGE TASK SEATING

RANHD 24/7

Chair Operating Instructions

1. Lumbar

Adjust the lumbar by turning the knob clockwise for more support or counterclockwise for less support.

2. Seat Angle

To tilt the seat forward, first recline slightly in the chair and then rotate handle clockwise until desired angle is reached. To return to a neutral position, rotate handle counterclockwise.

3. Seat Height

Lift the paddle up and simultaneously lift your weight from the seat while raising or lowering the seat. Release the lever to lock the seat in position.

4. Back Angle

To adjust the backrest angle, lift the paddle up lean back to the desired position. Release the paddle to lock in position.

5. Tilt Lock

To adjust the recline angle, push the paddle forwards to unlock it. Recline to the desired position and push the paddle back to lock in place.

6. Back Height

Slowly lift the back until you have the appropriate back support. If the back is too high, lift the back all the way up and then lower to the first position.

7. Arm Height & Pad

Depress and hold the button on the side of the arm and lift or lower to desired height. Arm pads can slide forward and backward and side to side, as well as pivot inward.

8. Arm Width

To adjust the arm width, loosen the knob found under the seat, move the arm to the desired width and tighten the knob to lock in place.

9. Seat Depth

Lift up on the lever, slide the seat forward or backward, and release it into one of the five desired locking positions.

10. Tension Control

Turn knob clockwise to increase seat tilt tension and counterclockwise to decrease tension.

