

RANGE TASK SEATING

RANMB (Mid-back) & RANHB (High-back)
Chair Operating Instructions



RANGE TASK SEATING

RANMB (Mid-back) & RANHB (High-back) Chair Operating Instructions

1. Lumbar

Adjust the lumbar by turning the knob clockwise for more support or counterclockwise for less support.

2. Arm Height & Pad

Depress and hold the button on the side of the arm and lift or lower to desired height. Arm pads can slide forward and backward and side to side, as well as pivot inward.

3. Arm Width

To adjust the arm width, loosen the knob found under the seat, move the arm to the desired width and tighten the knob to lock in place.

4. Seat Height

Lift the paddle up and simultaneously lift your weight from the seat while raising or lowering the seat. Release the lever to lock the seat in position.

5. Back Height

Slowly lift the back until you have the appropriate back support. If the back is too high, lift the back all the way up and then lower to the first position.

6. Tension Control

Turn knob clockwise to increase seat tilt tension and counterclockwise to decrease tension.

7. Seat Depth

Lift up on the lever, slide the seat forward or backward, and release it into one of the five desired locking positions.

8. Tilt Lock

To adjust the recline angle, push the paddle forwards to unlock it. Recline to the desired position and push the paddle back to lock in place.

